

Rockwell Automation Library of Process Objects: E300 Overload Relay (EtherNet/IP) (P_E3000vId)

Version 3.1



Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

IMPORTANT

Identifies information that is critical for successful application and understanding of the product.

Labels may also be on or inside the equipment to provide specific precautions.



SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



ARC FLASH HAZARD: Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

Preface	Software Compatibility.....	5
	Additional Resources.....	5
E300 Overload Relay (EtherNet/IP) (P_E3000vId)	Guidelines.....	8
	Functional Description.....	8
	Required Overload Configuration.....	9
	Required Files.....	10
	Controller File.....	10
	Visualization Files.....	10
	Controller Code.....	11
	E300 Overload Relay (EtherNet/IP) InOut Structure.....	11
	E300 Overload Relay (EtherNet/IP) Input Structure.....	12
	E300 Overload Relay (EtherNet/IP) Output Structure.....	14
	E300 Overload Relay (EtherNet/IP) Local Configuration Tags.....	17
	Operations.....	18
	Modes.....	18
	Alarms.....	18
	Simulation.....	18
	Execution.....	19
	Programming Example.....	19
	Display Elements.....	21
	Status/Quality/Threshold Indicators.....	22
	Alarm Indicators.....	23
	Using Display Elements.....	24
	Faceplate.....	26
	Operator Tab.....	27
	Maintenance Tab.....	30
	Engineering Tab.....	34
	Diagnostics Tab.....	37
	Alarms Tab.....	40
	E300 Overload Relay (EtherNet/IP) Faceplate Help.....	42

Notes:

This document is complete for version 3.1 of the Rockwell Automation Library of Process Objects.

Software Compatibility

For the latest compatible software information and to download the Rockwell Automation Library of Process Objects, see the Product Compatibility and Download Center at <http://www.rockwellautomation.com/rockwellautomation/support/pcdc.page>.

For general library considerations, see Rockwell Automation Library of Process Objects, publication [PROCES-RM002](#).

Additional Resources

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
PlantPAx® Process Automation System Selection Guide, publication PROCES-SG001	Provides information to assist with equipment procurement for your PlantPAx system.
PlantPAx Process Automation System Reference Manual, publication PROCES-RM001	Provides characterized recommendations for implementing your PlantPAx system.
Rockwell Automation Library of Process Objects, publication PROCES-RM002	Provides general considerations for the PlantPAx system library of process objects.
FactoryTalk® View Machine Edition User Manual, publication VIEWME-UM004	Provides details on how to use this software package for creating an automation application.
FactoryTalk View Site Edition User Manual, publication VIEWSE-UM006	Provides details on how to use this software package for developing and running human-machine interface (HMI) applications.
Logix5000™ Controllers Add-On Instructions Programming Manual, publication 1756-PM010	Provides information for designing, configuring, and programming Add-On Instructions.
Rockwell Automation Library of Process Objects: Common Alarm Block (P_Alarm) Reference Manual, publication SYSLIB-RM002	Details how to monitor an input condition to raise an alarm.
Rockwell Automation Library of Process Objects: E1 Plus™ Overload Relay (P_E1PlusE) Reference Manual, publication SYSLIB-RM049A-EN-P	Details how to control and monitor a 193-ETN (E1 Plus on EtherNet/IP) overload relay.
Rockwell Automation Library of Process Objects: E3™/E3 Plus™ Overload Relay (EtherNet/IP) (P_E30vld) Reference Manual, publication SYSLIB-RM050A-EN-P	Details how to control and monitor a 193/592-EC1, -EC2, -EC3, or -EC5 (E3 or E3 Plus) overload relay.

You can view or download publications at <http://www.rockwellautomation.com/literature/>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

Notes:

E300 Overload Relay (EtherNet/IP) (P_E300Ovld)

The P_E300Ovld (E300 Overload Relay) Add-On Instruction controls and monitors a 193-ECM-ETR (E300™ on EtherNet/IP) overload relay.

The image shows two panels: 'Add-On Instruction' and 'Faceplate'.

Add-On Instruction: A list of variables for the P_E300Ovld instruction, including Inp, Ref_TripCodeList, Ref_WarningCodeList, Inp_Trip, Inp_TripReset, Out_TripReset, Out_RemoteTrip, Val_PctTherm, Val_CurImbal, Val_AvgPctFLA, Val_AvgCurr, Val_GndFaultCurr, Val_AvgVolts, Val_TotRealPwr, Val_TotReactPwr, Val_TotAppPwr, Val_PwrFact, Sts_MotorCurr, Sts_GFCurr, Sts_MotorVolts, Sts_InpPI00, Sts_InpPI01, Sts_OutPI00, Sts_LocalResetReqd, Sts_Err, Sts_Warn, Sts_Trip, and Sts_IOFault.

Faceplate: A graphical interface for the P_E300Ovld - Motor Overload Relay. It includes a 'Home - Operator' button, a status indicator for 'Average % Full Load Amps' (0.0), a 'Comm Good' indicator, and a table of motor status data.

Parameter	Value
Thermal Utilization	14.00 %
Average Full Load Amps	35 %
Power Factor	95.50 %

Additional status indicators include 'Motor Current Present' and 'Motor Voltage Present', both shown as active (blue circles).

Guidelines

Use this instruction to monitor an Allen-Bradley E300 series motor overload relay (193-ECM-ETR series) by using its built-in EtherNet/IP interface.

This instruction monitors the overload relay for warning and trip conditions, displays motor average current and phase currents, and provides commands to initiate a remote trip and a remote trip reset.

This instruction supports add-on options for the overload relay, including its operator interface, sensors for voltages and ground fault current, and optional discrete I/O and analog I/O modules.

This instruction provides alarms for trip warning, relay trip and I/O communication failure.

Do **not** use this instruction for other Allen-Bradley Motor overload relays, such as the E1 Plus, E3, E3 Plus, or 857 series.

- For the E1 Plus series of motor overload relays using the 193-ETN EtherNet/IP interface, use the P_E1PlusE Add-On Instruction instead.
- For the E3 and E3 Plus series of motor overload relays, use the P_E3Ovld Add-On Instruction.
- Other overload relays may be monitored by specific logic or supported by future Add-On Instructions.

Functional Description

The P_E300Ovld (E3/E3 Plus overload relay) Add-On Instruction provides:

- Warning of impending overloads
- Identification of overload trip conditions
- Countdown of time until overload trip can be reset
- Configurable command to initiate a remote test trip
- Configurable command to initiate a trip reset

IMPORTANT Three trips within a configurable time requires resetting the trip locally (at the relay).

- Monitoring of states of relay's discrete inputs and discrete outputs
- Monitoring of various current, voltage and ground fault values (if available)
- Monitoring of I/O communication faults
- Alarms for Trip Warning, Overload Trip and I/O Fault
- Supports HMI 'breadcrumbs' for Alarm Inhibited, Bad Configuration, and Not Ready

Required Overload Configuration

Be certain to set up the E300 Datalinks as follows.

IMPORTANT 'User Choice' Datalinks are not used by this AOI and can be left unused or set up for your application.

- Input Assembly:
 - Drive Status (standard)
 - Feedback (standard)
 - Datalinks:
 1. Time to Reset (Par 3)
 2. Time to Start (Par 31)
 3. Trip History #0 (Par 127)
 4. Warning History #0 (Par 133)
 5. Invalid Configuration Parameter Number (Par 38)
 6. User choice #1
 7. User choice #2
 8. User choice #3
- Output Assembly

The P_E300Ovld Add-On Instruction only uses the Remote Trip and Remote Trip Reset command bits in the output assembly.

Required Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

Controller File

The P_E300Ovld_3_1-00_AOIL5X Add-On Instruction must be imported into the controller project to be used in the controller configuration. The service release number (boldfaced) can change as service revisions are created.

Visualization Files

The following files for this Add-On Instruction can be downloaded from the Product Compatibility and Download Center at <http://www.rockwellautomation.com/rockwellautomation/support/pcdc.page>.

IMPORTANT Files must be imported in the following order: image files, then global object files, and then graphic files. This order is required to properly configure the visualization files.

Table 1 - P_E300Ovld Visualization File Types

Application Type	File Type	FactoryTalk View SE Software	FactoryTalk View ME Software	Description
Graphics - Displays	GFX	(RA-BAS) P_E300Ovld-Faceplate	(RA-BAS-ME) P_E300Ovld-Faceplate	The faceplate display used for the object.
		(RA-BAS) P_E300Ovld-Help	(RA-BAS-ME) P_E300Ovld-Help	Help information that is accessed from the P_E300Ovld Help faceplate.
		(RA-BAS) Common-AnalogEdit	N/A	Faceplate used for analog input data entry. The FactoryTalk View ME faceplates use the native analog input data entry so no file is required.
		(RA-BAS) P_Alarm-Faceplate	(RA-BAS-ME) P_Alarm-Faceplate	The alarm faceplate display used for the object.
		(RA-BAS) P_Alarm-Help	(RA-BAS-ME) P_Alarm-Help	Alarm Help information that is accessed from the P_Alarm Help faceplate.
Graphics - Global Objects	GGFX	(RA-BAS) Common Faceplate Objects	(RA-BAS-ME) Common Faceplate Objects	Common global objects used on all Process Object faceplates.
		(RA-BAS) Process Alarm Objects	(RA-BAS-ME) Process Alarm Objects	Global objects used for alarming on Process Object faceplates.
		(RA-BAS) Process Faceplate Motor Objects	(RA-BAS-ME) Process Faceplate Motor Objects	Global Objects used on motor device faceplates.
		(RA-BAS) Process Graphics Library	(RA-BAS-ME) Process Graphics Library	Common global objects in the graphics library for this instruction.
		(RA-BAS) Process Help Objects	(RA-BAS-ME) Process Help Objects	Global objects used for all Process Objects help displays.

Table 1 - P_E300Ovld Visualization File Types

Application Type	File Type	FactoryTalk View SE Software	FactoryTalk View ME Software	Description
Graphics - Images	BMP	All .png files in the images folder	All .png files in the images folder	These are the common icons used in the global objects and faceplates for all Process Objects.
HMI Tags	CSV	N/A	FTVME_PlantPAxLib_Tags_3_1_00.csv ⁽¹⁾	These tags must be imported into the FactoryTalk View ME project to support switching tabs on any Process Object faceplate.

(1) The service release number (boldfaced) can change as service revisions are created.

Controller Code

This section describes the parameter references for this Add-On Instruction.

E300 Overload Relay (EtherNet/IP) InOut Structure

InOut parameters are used to link the Add-On Instruction to external tags that contain necessary data for the instruction to operate. These external tags must be of the data type shown.

Tag Name	Data Type	Description
Inp	P_E300Ovld_Inp	E300 Overload (193-ECM-ETR) Input Structure.
Ref_TripCodeList	P_DescList[*]	Tag containing List of Trip History Codes and Descriptions.
Ref_WarningCodeList	P_DescList[*]	Tag containing List of Warning History Codes and Descriptions.

E300 Overload Relay (EtherNet/IP) Input Structure

Input parameters include the following:

- Input data elements (Inp_) are typically used to connect field inputs from I/O modules or signals from other objects.
- Configuration data elements (Cfg_) are used to set configurable capabilities and features of the instruction.
- Commands (PCmd_, OCmd_, MCmd_) are used by program logic, operators, and maintenance personnel to request instruction actions.

Table 2 - P_E3000vld Input Parameters

Input parameter	Data Type	Alias For	Default	Description
EnableIn	BOOL		1	<p>Ladder Diagram: If the rung-in condition is true, the instruction's Logic routine executes. If the rung-in condition is false, the instruction's EnableInFalse routine executes.</p> <p>Function Block Diagram: If true, or not connected, the instruction's Logic routine executes. If the parameter is exposed as a pin and wired, and the pin is false, the instruction's EnableInFalse routine executes.</p> <p>Structured Text: No effect. The instruction's Logic routine executes.</p>
Inp_Trip	BOOL		0	1 = Send Remote Trip request to overload relay.
Inp_TripReset	BOOL		0	1 = Send Trip Reset request to overload relay.
Inp_Reset	BOOL		0	1 = Reset all latched alarms.
Cfg_AllowOperTrip	BOOL		0	1 = Remote Trip function is available to Operator.
Cfg_AllowOperReset	BOOL		0	1 = Trip Reset function is available to operator.
Cfg_AllowMaintTrip	BOOL		0	1 = Remote Trip function is available to Maintenance.
Cfg_AllowMaintReset	BOOL		1	1 = Trip Reset function is available to Maintenance.
Cfg_PCmdClear	BOOL		1	<p>When this parameter is 1, program commands are cleared once they are acted upon. When set to 0, program commands remain set until cleared by the application program logic.</p> <p>IMPORTANT: Clearing this parameter online can cause unintended program command execution.</p>
Cfg_HasWarnAlm	BOOL	Warn.Cfg_Exists	0	These parameters determine whether the corresponding alarm exists and is checked or if the alarm does not exist and is not used. When these parameters are 1, the corresponding alarm exists.
Cfg_HasTripAlm		Trip.Cfg_Exists		
Cfg_HasIOFaultAlm		IOFault.Cfg_Exists		
Cfg_WarnResetReqd	BOOL	Warn.Cfg_ResetReqd	0	<p>These parameters determine whether a reset is required to clear the alarm status. When these parameters are 1, the alarm is latched ON when the alarm occurs. After the alarm condition returns to normal, a reset is required to clear the alarm status (for example, OCmd_Reset, Inp_Reset, or Trip.OCmd_Reset are required to clear Alm_Trip alarm after the alarm is set and the value returns to normal). When this parameter is 0, no reset is required and the alarm status is cleared when the alarm condition returns to normal.</p> <p>IMPORTANT: If the reset clears the alarm, it also acknowledges the alarm.</p>
Cfg_TripResetReqd		Trip.Cfg_ResetReqd		
Cfg_IOFaultResetReqd		IOFault.Cfg_ResetReqd		
Cfg_WarnAckReqd	BOOL	Warn.Cfg_AckReqd	1	These parameters determine whether an acknowledgement is required for an alarm. When these parameters are 1, the acknowledge (ack) bit is cleared when the alarm occurs. An acknowledge command (for example, PCmd_TripAck or Trip.OCmd_Ack) is required to acknowledge the alarm. When set to 0, the Acknowledge bit is set when an alarm occurs indicating an acknowledged alarm and no acknowledge command is required.
Cfg_TripAckReqd		Trip.Cfg_AckReqd		
Cfg_IOFaultAckReqd		IOFault.Cfg_AckReqd		

Table 2 - P_E3000vld Input Parameters

Input parameter	Data Type	Alias For	Default	Description
Cfg_WarnSeverity	INT	Warn.Cfg_Severity	500	These parameters determine the severity of each alarm. This drives the color and symbol that are used to indicate alarm status on the faceplate and global object. The following are valid values: 1...250 = Low 251...500 = Medium 501...750 = High 751...1000 = Urgent IMPORTANT: For FactoryTalk View software version 7.0, these severity parameters drive only the indication on the global object and faceplate. The Alarms and Events definition of severity drives the color and symbol that is used on the alarm banner and alarm summary as well as the value returned by FactoryTalk Alarms and Events display commands.
Cfg_TripSeverity		Trip.Cfg_Severity	750	
Cfg_IOFaultSeverity		IOFault.Cfg_Severity	1000	
Cfg_PulseT	DINT		5	Time (sec) to pulse Trip Reset or Remote Trip output to E300.
Cfg_LocalResetReqdT	DINT		3600	No more than (1, 2, or 3) remote Trip Resets are allowed in this amount of time (seconds).
Cfg_LocalResetReqdNum	DINT		3	No more than this many remote Trip Resets are allowed in (configured) time (1, 2, or 3).
PCmd_Trip	BOOL		0	When Cfg_PCcmdClear is 1: <ul style="list-style-type: none"> Set PCmd_Trip to 1 to send remote trip request to overload relay Set PCmd_TripReset to 1 to send trip reset request to overload relay These parameters reset automatically When Cfg_PCcmdClear is 0: <ul style="list-style-type: none"> Set PCmd_Trip to 1 to send remote trip request to overload relay Set PCmd_TripReset to 1 to send trip reset request to overload relay These parameters do not reset automatically
PCmd_TripReset				
PCmd_Reset	BOOL		0	<ul style="list-style-type: none"> Set PCmd_Reset to 1 to reset all alarms requiring reset This parameter is always reset automatically
PCmd_WarnAck	BOOL	Warn.PCmd_Ack	0	<ul style="list-style-type: none"> Set PCmd_<Alarm>Ack to 1 to Acknowledge alarm The parameter is reset automatically
PCmd_TripAck		Trip.PCmd_Ack		
PCmd_IOFaultAck		IOFault.PCmd_Ack		
PCmd_WarnSuppress	BOOL	Warn.PCmd_Suppress	0	When Cfg_PCcmdClear is 1: <ul style="list-style-type: none"> Set PCmd_<Alarm>Suppress to 1 to suppress alarm Set PCmd_<Alarm>Unsuppress to 1 to unsuppress alarm These parameters reset automatically When Cfg_PCcmdClear is 0: <ul style="list-style-type: none"> Set PCmd_<Alarm>Suppress to 1 to suppress alarm Set PCmd_<Alarm>Suppress to 0 to unsuppress alarm PCmd_<Alarm>Unsuppress is not used These Parameters do not reset automatically
PCmd_TripSuppress		Trip.PCmd_Suppress		
PCmd_IOFaultSuppress		IOFault.PCmd_Suppress		
PCmd_WarnUnsuppress	BOOL	Warn.PCmd_Unsuppress	0	When Cfg_PCcmdClear is 0: <ul style="list-style-type: none"> Set PCmd_<Alarm>Suppress to 1 to suppress alarm Set PCmd_<Alarm>Suppress to 0 to unsuppress alarm PCmd_<Alarm>Unsuppress is not used These Parameters do not reset automatically
PCmd_TripUnsuppress		Trip.PCmd_Unsuppress		
PCmd_IOFaultUnsuppress		IOFault.PCmd_Unsuppress		
PCmd_WarnUnshelve	BOOL	Warn.PCmd_Unshelve	0	<ul style="list-style-type: none"> Set PCmd_<Alarm>Unshelve to 1 to Unshelve alarm The parameter is reset automatically
PCmd_TripUnshelve		Trip.PCmd_Unshelve		
PCmd_IOFaultUnshelve		IOFault.PCmd_Unshelve		
OCmd_Trip	BOOL		0	Operator command to send Remote Trip or Trip Reset request to overload relay.
OCmd_TripReset				
OCmd_Reset	BOOL		0	Operator Command to Reset all Alarms requiring Reset.
OCmd_ResetAckAll	BOOL		0	Operator Command to Reset all Alarms and latched Shed conditions.

E300 Overload Relay (EtherNet/IP) Output Structure

Output parameters include the following:

- Output data elements (Out_) are the primary outputs of the instruction, typically used by hardware output modules; however, they can be used by other application logic.
- Value data elements (Val_) are numeric outputs of the instruction for use by the HMI. Values also can be used by other application logic or software packages.
- Source and Quality data elements (SrcQ_) are outputs of the instruction used by the HMI to indicate PV source and quality.
- Status data elements (Sts_) are bit outputs of the instruction for use by the HMI. Status bits also can be used by other application logic.
- Error data elements (Err_) are outputs of the instruction that indicate a particular configuration error. If any Err_ bit is set then the Sts_Err configuration error summary status is set and the Invalid Configuration indicator is displayed on the HMI.
- Not Ready data elements (Nrdy_) are bit outputs of the instruction for use by the HMI for displaying the Device Not Ready indicator. Status bits can also be used by other application logic.
- Alarm data elements (Alm_) are outputs of the instruction that indicate a particular alarm has occurred.
- Acknowledge data elements (Ack_) are outputs of the instruction that indicate the corresponding alarm has been acknowledged.
- Ready data elements (Rdy_) are bit outputs of the instruction used by the HMI to enable or disable Command buttons and Setting entry fields.

Table 3 - P_E3000vid Output Parameters

Output Parameter	Data Type	Alias For	Description
EnableOut	BOOL		Enable Output: The EnableOut signal is not manipulated by this instruction. Its output state always reflects EnableIn Input state.
Out_TripReset	BOOL		1 = Reset overload trip.
Out_RemoteTrip	BOOL		1 = Initiate remote trip.
Val_PctTherm	REAL		Percent Thermal Capability Utilized (%).
Val_CurrImbal	REAL		Current Imbalance (%).
Val_AvgPctFLA	REAL		Average Percent Full Load Amps (%).
Val_AvgCurr	REAL		Average Current (Amps).
Val_L1Curr	REAL		L1 Phase Current (Amps).
Val_L2Curr	REAL		L2 Phase Current (Amps).
Val_L3Curr	REAL		L3 Phase Current (Amps).
Val_GndFaultCurr	REAL		Ground Fault Current (Amps).
Val_AvgVolts	REAL		Average Line-to-Line Voltage (Volts).
Val_L1L2Volts	REAL		L1 Phase to L2 Phase Voltage (Volts).
Val_L2L3Volts	REAL		L2 Phase to L3 Phase Voltage (Volts).
Val_L3L1Volts	REAL		L3 Phase to L1 Phase Voltage (Volts).

Table 3 - P_E3000vld Output Parameters

Output Parameter	Data Type	Alias For	Description
Val_TotRealPwr	REAL		Total Real Power (kW).
Val_TotReactPwr	REAL		Total Reactive Power (kVAR).
Val_TotAppPwr	REAL		Total Apparent Power (kVA).
Val_PwrFact	REAL		Power Factor (%).
Val_MinToReset	DINT		Time until overload can be reset (minutes in mmm:ss).
Val_SecToReset	DINT		Time until overload can be reset (seconds in mmm:ss).
Val_MinToStart	DINT		Time until motor can be started (minutes in mmm:ss).
Val_SecToStart	DINT		Time until motor can be started (seconds in mmm:ss).
Val_TripCode	INT		Overload Trip History 0 (most recent trip) Code (enumeration).
Val_WarningCode	INT		Overload Warning History 0 (most recent warning) Code (enumeration).
Val_InvCfgParam	INT		ID number of misconfigured parameter in E300 (Par #).
SrcQ_IO	SINT		I/O signal source and quality.
SrcQ			Final device status source and quality: GOOD 0 = I/O live and confirmed good quality 1 = I/O live and assumed good quality 2 = No feedback configured, assumed good quality TEST 8 = Device simulated 9 = Device loopback simulation 10 = Manually entered value UNCERTAIN 16 = Live input, off-specification 17 = Value substituted at device/bus 18 = Value substituted by maintenance (Has and not Use) 19 = Shed, using last good value 20 = Shed, using replacement value BAD 32 = Signal failure (out-of-range, NaN, invalid combination) 33 = I/O channel fault 34 = I/O module fault 35 = Bad I/O configuration (for example, scaling parameters)
Val_Fault	SINT		Device Fault Status: 0 = None 15 = Warning 31 = Tripped 31 = Local Reset Required 32 = I/O Fault 34 = Config Error
Val_Notify	SINT		Current alarm level and acknowledgement (enumeration): 0 = No alarm 1 = Alarm cleared: a reset or acknowledge is required 2 = Low (acknowledged) 3 = Low (unacknowledged) 4 = Medium (acknowledged) 5 = Medium (unacknowledged) 6 = High (acknowledged) 7 = High (unacknowledged) 8 = Urgent (acknowledged) 9 = Urgent (unacknowledged)
Sts_MotorCurr	BOOL		1 = Motor current is present.
Sts_GFCurr	BOOL		1 = Ground Fault current is present.
Sts_MotorVolts	BOOL		1 = Motor voltage preset.

Table 3 - P_E300Ovld Output Parameters

Output Parameter	Data Type	Alias For	Description
Sts_EStartEna	BOOL		1 = Emergency Start capability is enabled.
Sts_DevLgxEna	BOOL		1 = Device Logix capability is enabled.
Sts_FdbkTmoEna	BOOL		1 = Feedback timeout enabled.
Sts_OpStaPres	BOOL		1 = E300 has Operator Station present.
Sts_VoltSense	BOOL		1 = Voltage sensing capability is present (for example, VIG).
Sts_IntGndFaultSense	BOOL		1 = Internal Ground Fault sensing is present (IG or VIG).
Sts_ExtGndFaultSense	BOOL		1 = External Ground Fault Sensing is present (IG or VIG).
Sts_PTCSense	BOOL		1 = PTC Temperature sensing is present.
Sts_InpPt00...Sts_InpPt05	BOOL		Status of discrete input Pt00...Pt05.
Sts_OutPt00...Sts_OutPt02	BOOL		Status of discrete output Pt00...Pt02.
Sts_DeviceSts1	INT		Device status 1 (Par 21) (Control, Sensing, Expansion Module presence).
Sts_InpSts1	INT		Input status 1 (Par 17) (Discrete Expansion Module inputs).
Sts_OutSts	INT		Output status (Par 18) (Discrete Expansion Module outputs).
Sts_OpSta	INT		Local Operator station status (Par 19).
Sts_CurrentTrip	INT		Current Trip status bits (Par 4).
Sts_CurrentWarning	INT		Current Warning status bits (Par 10).
Sts_VoltageTrip	INT		Voltage Trip status bits (Par 5).
Sts_VoltageWarning	INT		Voltage Warning status bits (Par 11).
Sts_PowerTrip	INT		Power Trip status bits (Par 6).
Sts_PowerWarning	INT		Power Warning status bits (Par 12).
Sts_ControlTrip	INT		Control Trip status bits (Par 7).
Sts_ControlWarning	INT		Control Warning status bits (Par 13).
Sts_AnalogTrip	INT		Analog Trip status bits (Par 8).
Sts_AnalogWarning	INT		Analog Warning status bits (Par 14).
Sts_DevLgxOutputs	INT		Device Logix output bits (Par 348).
Sts_LocalResetReqd	BOOL		Too many remote resets: go to starter, find cause, and reset there.
Sts_NotRdy	BOOL		1 = Device Not Ready, see detail bits for reason.
Nrdy_Trip	BOOL		1 = Device Not Ready: <ul style="list-style-type: none"> • Tripped (at device or by command) • I/O Fault (shed requires reset) • Overload powerup not complete.
Nrdy_IOFault			
Nrdy_OvldNR			
Sts_Almlnh	BOOL		1 = An alarm is shelved, disabled, or suppressed: display icon.
Sts_Err	BOOL		1 = Error in Config: see detail bits for reason.
Err_Timer	BOOL		1 = Error in Config: Reset pulse timer preset (use 0...2,147,483).
Err_Alarm	BOOL		1 = Error in Config: Alarm Min On Time or Severity.
Sts_Warn	BOOL	Warn.Inp	1 = Warning of impending trip (See Sts_WarnBits for reason).
Sts_Trip		Trip.Inp	1 = Overload tripped (See Sts_TripBits for reason).
Sts_IOFault		IOFault.Inp	I/O communication fault status (0 = OK, 1 = Bad).

Table 3 - P_E3000vld Output Parameters

Output Parameter	Data Type	Alias For	Description
Alm_Warn	BOOL	Warn.Alm	1 = Alarm: warning of impending trip, overload tripped, or I/O Fault alarm.
Alm_Trip		Trip.Alm	
Alm_IOFault		IOFault.Alm	
Ack_Warn	BOOL	Warn.Ack	1 = Trip Warning alarm, Overload Trip alarm, or I/O Fault alarm has been acknowledged.
Ack_Trip		Trip.Ack	
Ack_IOFault		IOFault.Ack	
Sts_WarnDisabled	BOOL	Warn.Disabled	1 = Trip Warning alarm, Overload Trip, or I/O Fault alarm has been disabled by Maintenance.
Sts_TripDisabled		Trip.Disabled	
Sts_IOFaultDisabled		IOFault.Disabled	
Sts_WarnShelved	BOOL	Warn.Shelved	1 = Trip Warning alarm, Overload Trip, or I/O Fault alarm has been shelved by Operator.
Sts_TripShelved		Trip.Shelved	
Sts_IOFaultShelved		IOFault.Shelved	
Sts_WarnSuppressed	BOOL	Warn.Suppressed	1 = Trip Warning alarm, Overload Trip, or I/O Fault alarm has been suppressed by Program.
Sts_TripSuppressed		Trip.Suppressed	
Sts_IOFaultSuppressed		IOFault.Suppressed	
Rdy_Trip	BOOL		1 = Ready to receive OCmd_Trip or OCmd_TripReset (enables HMI button).
Rdy_TripReset			
Rdy_Reset	BOOL		1 = At least one Alarm requires Reset.
Rdy_ResetAckAll	BOOL		1 = At least one alarm or latched Shed condition requires a reset or acknowledgement.
P_E3000vld	BOOL		Unique Parameter Name for auto-discovery.

E300 Overload Relay (EtherNet/IP) Local Configuration Tags

Configuration parameters that are array, string, or structure data types cannot be configured as parameters for Add-On Instructions. Configuration parameters of these types appear as local tags to the Add-On Instruction. Local tags can be configured through the HMI faceplates or in RSLogix™ 5000 software by opening the instruction logic of the Add-On Instruction instance and then opening the Data Monitor on a local tag. These parameters cannot be modified by using controller logic or RSLogix 5000 software export/import functionality.

Tag Name	Data Type	Default	Description
Cfg_Desc	STRING_40	'Motor Overload Relay'	Description for display on HMI. This string is shown in the title bar of the faceplate.
Cfg_InpPt00Txt	STRING_20	'Starter Aux Contact'	Text for discrete inputs Pt00...Pt05 labels on HMI. These strings appear on page 2 of the Maintenance tab.
Cfg_InpPt01Txt		' '	
Cfg_InpPt02Txt		' '	
Cfg_InpPt03Txt		' '	
Cfg_InpPt04Txt		' '	
Cfg_InpPt05Txt		' '	

Tag Name	Data Type	Default	Description
Cfg_Label	STRING_20	'Overload Relay'	Label for graphic symbol displayed on HMI. This string appears on the graphic symbol.
Cfg_OutPt00Txt	STRING_20	'Starter Energized'	Text for discrete outputs Pt00 . . . Pt02 labels on HMI. These strings appear on page 2 of the Maintenance tab.
Cfg_OutPt01Txt		' '	
Cfg_OutPt02Txt		' '	
Cfg_Tag	STRING_20	'P_E300Ovld'	Tagname for display on HMI. This string is shown in the title bar of the faceplate.

Operations

This section describes the primary operations for Add-On Instructions.

Modes

The P_E300Ovld Add-On Instruction does not have modes and does not contain a P_Mode instruction instance. Operator and Program commands are accepted at any time.

Alarms

The P_E300Ovld instruction uses the following alarms, implemented by using embedded P_Alarm.

Alarm Name	P_Alarm Name	Description
Warn	Warning Alarm	The Pending Trip Warning alarm is triggered when a motor overload condition is occurring and an overload is imminent.
Trip	Trip Alarm	The Overload Trip alarm occurs when the overload has tripped.
IOFault	I/O Fault Alarm	The I/O Fault alarm is triggered when a controller or communication fault is detected.

Refer to the Rockwell Automation Library of Process Objects: Common Alarm Block (P_Alarm) Reference Manual, publication [SYSLIB-RM002](#), for more information.

Simulation

The P_E300Ovld Add-On Instruction does not have a Simulation capability.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	No EnableInFalse logic is provided. Instruction parameters hold their last values.
Powerup (prescan, first scan)	Any commands received before first scan are discarded. Embedded P_Alarm instructions are handled in accordance with their standard power-up procedures. Refer to the Reference Manual for the P_Alarm Instruction for more information.
Postscan (SFC transition)	No SFC postscan logic is provided.


Refer to the Logix5000 Controllers Add-On Instructions Programming Manual, publication [1756-PM010](#), for more information.

Programming Example


The following example shows the P_E300Ovld in both a strictly ladder and a combined ladder/function block context.

In both cases, ladder logic is used to copy the Module Defined Data Type for the E300 Overload Module (AB:E300:I:0) to the User Defined Type for the E300 Overload (193-ECM-ETR) Input Structure (P_E300Ovld_Inp).


A complete ladder example is shown below.



An extended example using Function Blocks is also shown. In this case, the same COP instruction is used in ladder logic, followed by a Jump to Subroutine (JSR) to a Function Block routine.



The Function Block Routine shows a typical configuration with the P_E300Ovld connected to an interlock (P_Intlk) block followed by a motor (P_Motor).



Display Elements

A display element (global object) is created once and can be referenced multiple times on multiple displays in an application. When changes are made to the original (base) object, the instantiated copies (reference objects) are automatically updated. Use of global objects, in conjunction with tag structures in the ControlLogix system, aid consistency and save engineering time.

Display Element Name	Display Element	Description
GO_P_Ovld GO_P_Ovld1		Standard E300 overload relay global objects.


Graphic symbols provide end-users with the following:

- Information on the overload relay's current state
- Touch field to open the object's faceplate
- Tooltip to display the object's configured tag and description

The graphic symbol without the label is designed to be placed directly adjacent to (below) the associated motor's graphic symbol.






Common attributes of the overload graphic symbols include the following:

- Graphical representation of the device
- Status/quality indicators
- Present Value of average motor current
- Alarm indicator that changes color for the severity of the alarm
- Color changing alarm border that blinks on unacknowledged alarm



Status/Quality/Threshold Indicators

One of these symbols appears to the left of the graphic symbol when the described condition is true.

Graphic Symbol	Description
	Invalid configuration.
	I/O Communication bad.
	I/O Communication uncertain.
	Device not ready.
	Device is in Maintenance Bypass. IMPORTANT: This indicator is not used in the P_E3000vld instruction.
No symbol displayed	I/O communication OK and configuration valid.

TIP When the Invalid Configuration indicator appears, you can find what configuration setting is invalid by following the indicators. Click the graphic symbol to open the faceplate. The Invalid Configuration indicator appears next to the appropriate tab at the top of the faceplate to guide you in finding the configuration error. Once you navigate to the tab, the misconfigured item is flagged with this indicator or appears in a magenta box.

For the E300 overload relay instruction, the Invalid Configuration indicator appears under the following conditions:

- The Reset Pulse timer is set to a value less than zero or greater than 2,147,483 seconds.
- The Alarm Minimum On time is set to a value less than zero or greater than 2,147,483 seconds.
- Alarm Severity is set to a value less than 1 or greater than 1000.

TIP When the Not Ready indicator appears, you can find what condition is preventing operation by following the indicators. Click the graphic symbol to open the faceplate. The Not Ready indicator appears next to the appropriate tab at the top of the faceplate to guide you in finding the condition. When you navigate to the tab, the condition preventing operation is flagged.







For the E300 overload relay instruction, the Device Not Ready indicator appears under the following conditions:

- The relay has been tripped at the device or by command.
- There is an I/O Fault.
- The I/O Fault has cleared, but its shed latch needs to be reset.
- The overload powerup has not been completed.

Alarm Indicators

One of these symbols appears to the left of the label to indicate the described alarm condition. The alarm border and label background blink if acknowledgement or reset of an alarm condition is required.

Table 4 - Alarm Indicators


Symbol	Border and Label Background	Description
	No change in color	Alarm Inhibit: an alarm is suppressed by the Program, disabled by Maintenance, or shelved by the Operator.
	White	Return to normal (no alarm condition), but a previous alarm has not been acknowledged.
	Blue	Low severity alarm.
	Yellow	Medium severity alarm.
	Red	High severity alarm.
	Magenta	Urgent severity alarm.
No symbol	No change in color	No alarm or alarm inhibit condition, and all alarms are acknowledged.

Refer to the Rockwell Automation Library of Process Objects: Common Alarm Block (P_Alarm) Reference Manual, publication [SYSLIB-RM002](#), for more information.

Using Display Elements


The global objects for P_300Ovld can be found in the global object file (RA-BAS) Process Graphics Library.ggfx. Follow these steps to use a global object.

1. Copy the global object from the global object file and paste it in the display file.



2. In the display, right-click the global object and choose Global Object Parameter Values.

The Global Object Parameter Values dialog box appears.



The global object parameters are as follows.

Parameter	Required	Description
#102	Y	Object tag to point to the name of the associated object Add-On Instruction in the controller.
#103	Y	Path used for display navigation features to other objects. Include program scope if tag is a program scope tag.
#120	N	Additional parameter to pass to the display command to open the faceplate. Typically used to define position for the faceplate.
#121	N	Additional parameter to pass to the display command to open the faceplate. if defining X and Y coordinate, separate parameters so that X is defined by #120 and Y is defined by #121. This lets these same parameters to be used in subsequent display commands originating from the faceplate.

- In the Value column, type the tag or value as specified in the Description column.

TIP Click the ellipsis (...) to browse and select a tag.
Values for items marked '(optional)' can be left blank.

- Click OK.


Faceplate

The P_E300Ovld faceplate consists of five tabs and each tab consists of one or more pages.

The title bar of the faceplate contains the value of local configuration tags Cfg_Tag and Cfg_Desc.

Tag - Description

The Operator tab is displayed when the faceplate is initially opened. Click the appropriate icon at the top of the faceplate to access a specific tab.




The faceplate provides the means for operators, maintenance workers, engineers, and others to interact with the P_E300Ovld instruction instance, including viewing its status and values and manipulating it through its commands and settings. When a given input is restricted via FactoryTalk View security, the required user security code letter is shown in the tables that follow.

Operator Tab

The Faceplate initially opens to the Operator ('Home') tab. From here, an operator can monitor the device status and if so configured, remotely trip or reset the overload relay.




The Operator tab shows the following information:

- Warning of impending overloads.
- Overload Status indicator.
- State of relay's inputs and outputs.
- State of I/O communications.
- Countdown of time until overload trip can be reset.
- Input Source and Quality indicator (See 'SrcQ' in the Output parameters table on [page 15](#) for details).









The following table shows the functions included on the Operator tab.

Table 5 - Operator Tab Description


Function	Action	Security
	Click to trip the overload relay.	Normal Operation of Devices (Code A) when Cfg_AllowOperTrip = 1 Equipment Maintenance (Code C) when Cfg_AllowMaintTrip = 1
	Click to reset the overload trip button.	Normal Operation of Devices (Code A) when Cfg_AllowOperTrip = 1 Equipment Maintenance (Code C) when Cfg_AllowMaintTrip = 1
	Click to reset and acknowledge all alarms.	Acknowledge Alarms (Code F)

The following table shows the alarm status symbols used on the Operator tab.

Table 6 - Operator Tab Alarm Status

Graphic Symbol	Alarm Status
	In Alarm (Active Alarm)
	In Alarm and Acknowledged
	Out of Alarm but not Acknowledged
	Alarm Suppressed (by Program)
	Alarm Disabled (by Maintenance)
	Alarm Shelved (by Operator)

Alarm indicators appear on the Operator tab when the corresponding alarm occurs.




Maintenance Tab

Maintenance personnel use the information and controls on the Maintenance tab to make adjustments to device parameters, troubleshoot and temporarily work around device problems, and disable the device for routine maintenance.

The Maintenance tab is divided into four pages.


Maintenance Tab Page 1

Page 1 of the Maintenance tab displays the values for the average current, average line-to-line voltage, current imbalance, total apparent power, total reactive power, and total real power. A diagram shows L1, L2, and L3 current, L1-L2 phase voltage, L3-L1 phase voltage, and L2-L3 phase voltage.



Maintenance Tab Page 2

Page 2 of the Maintenance tab shows whether the Control and Sensing Modules are present, plus up to 6 input indicators, and up to 3 output indicators.



The following table lists the functions on page 2 of the Maintenance tab.

Table 7 - Maintenance Tab Description

Function	Action	Security	Configuration Parameters
Time to pulse Trip Reset or Remote Trip output to E300 (seconds)	Type the number of seconds (0...2,147,483) to pulse.	Configuration and Tuning Maintenance (Code D)	Cfg_PulseT

Maintenance Tab Page 3


Page 3 of the Maintenance tab displays indicators for up to 4 discrete inputs and up to 2 discrete outputs for up to 4 discrete I/O modules. The values for the 3 analog inputs for up to 4 analog input modules are displayed.

Module	Inputs				Outputs	
	0	1	2	3	0	1
1	●	●	○	○	●	○
2	●	●	○	○	○	●
3	module not present					
4	module not present					

Module	Analog Inputs		
	0	1	2
1	module not present		
2	module not present		
3	module not present		
4	module not present		

Maintenance Tab Page 4

Page 4 of the Maintenance tab displays the DeviceLogix™ output status.



Engineering Tab

The Engineering tab provides access to device configuration parameters and ranges, options for device and I/O setup, displayed text, and faceplate-to-faceplate navigation settings, for initial system commissioning or later system changes.

The Engineering tab is divided into two pages.

Engineering Tab Page 1

On page 1 of the Engineering tab, you can configure the description, label, tag, Input labels, and output labels for the device.

The screenshot shows the configuration interface for the P_E300Ovld - Motor Overload Relay. The window title is "P_E300Ovld - Motor Overload Relay". The "Engineering" tab is selected, and page 1 is active. The configuration fields are as follows:

Field	Value
Label:	Overload Relay
Tag:	P_E300Ovld
Input Pt00 Label:	Fast Run Feedback
Input Pt01 Label:	Slow Run Feedback
Input Pt02 Label:	Disconnect Closed
Input Pt03 Label:	
Input Pt04 Label:	
Input Pt05 Label:	
Output Pt00 Label:	Fast Energized
Output Pt01 Label:	Slow Energized
Output Pt02 Label:	

At the bottom, there is a checked checkbox for "Clear Program Commands upon receipt".

Brackets on the right side of the image categorize the fields:


- Configure Device Description, Label, and Tag Text:** Label, Tag
- Configure Labels for Inputs:** Input Pt00 Label, Input Pt01 Label, Input Pt02 Label, Input Pt03 Label, Input Pt04 Label, Input Pt05 Label
- Configure Labels for Outputs:** Output Pt00 Label, Output Pt01 Label, Output Pt02 Label

The following table lists the functions on page 1 of the Engineering tab.

Table 8 - Engineering Tab Page 1 Description

Function	Action	Security	Configuration Parameters
Description	Type the device description to show on the faceplate title bar.	Engineering Configuration (Code E)	Cfg_Desc
Label	Type the label to show on the graphic symbol.		Cfg_Label
Tag	Type the tag name to show on the faceplate and in the Tooltip. IMPORTANT: Pausing the mouse over this field displays a tool tip with the configured Logix tag/path.		Cfg_Tag
Input Labels	Type the names for inputs Pt00...Pt05.		Cfg_InpPt00Txt...Cfg_InpPt05Txt
Output Labels	Type the names for outputs 1 and 2.		Cfg_OutPt00Txt...Cfg_OutPt02Txt
Clear Program Commands on Receipt	Check to clear Program commands on receipt.		Cfg_PCmdClear

Engineering Tab Page 2



The following table lists the functions on page 2 of the Engineering tab.

Table 9 - Engineering Tab Page 2 Description

Function	Action	Security	Configuration Parameters
Limit the maximum number of remote Trip Resets in a given time period to: x Resets in y Seconds	Type the maximum number of resets (1...3) in a given number of seconds (0...2,147,483). IMPORTANT: Setting the time to approximate 10 seconds or less allows unlimited Remote Trip resets.	Engineering Configuration (Code E)	<ul style="list-style-type: none"> • Cfg_LocalResetReqdNum • Cfg_LocalResetReqdT
Remote Trip function is available to: Maintenance User Operator User	Check to let the Maintenance and/or Operator User use the Remote Trip function.		<ul style="list-style-type: none"> • Cfg_AllowMaintTrip • Cfg_AllowOperTrip
Trip Reset function is available to: Maintenance User Operator User	Check to let the Maintenance and/or Operator User use the Trip Reset function.		<ul style="list-style-type: none"> • Cfg_AllowMaintReset • Cfg_AllowOperReset


Diagnostics Tab

The Diagnostic tab provides indications that are helpful in diagnosing or preventing device problems, which can include specific reasons a device is 'Not Ready', device warnings and faults, warning and fault history, and predictive/preventive maintenance data.

The Diagnostics tab is divided into 5 pages.

Diagnostic Tab Page 1

Page 1 of the Diagnostics tab has indicators for Device not Ready conditions and Device Configuration conditions.




The image above indicates the overload relay has tripped either at the device or by command. More information on this alarm can be seen on the [Alarms Tab on page 40](#).

Diagnostics Tab Pages 2 and 3


Page 2 of the Diagnostics tab has Trip and Warning indicators for Current and Voltage T conditions.

Page 3 of the Diagnostics tab has Trip and Warning indicators for Power Trip conditions.



Warning Indicators

Trip Indicators




Warning Indicators

Trip Indicators

Diagnostics Tab Pages 4 and 5


Page 4 of the Diagnostics tab has Trip and Warning indicators for Control Trip conditions.

Page 5 of the Diagnostics tab has Trip and Warning indicators for Analog Expansion Module Trips.



Warning Indicators

Trip Indicators




Warning Indicators

Trip Indicators

Alarms Tab

The Alarms Tab shows all of the available alarms for the device and their current status. From here, alarms can be acknowledged and reset. Click an alarm name to open the alarm detail faceplate for that alarm, where the alarm can be shelved by the operator, disabled by maintenance personnel, or configured by engineering.



Click an alarm name to open the P_Alarm faceplate for that alarm. From the P_Alarm faceplate, you can configure and perform additional operations on the alarm.



If an alarm is active, the panel behind the alarm changes color to match the severity of the alarm. The color of the bell icon at the top of the faceplate shows the highest active alarm's severity, and the icon blinks if any alarm is unacknowledged or requires reset.

The Alarms tab displays each alarm for this device. If the alarm is active, the panel behind the alarm changes color to match the severity of the alarm.

Color	Definition
Magenta	Urgent
Red	High
Yellow	Medium
Blue	Low
Background (Light Gray)	No alarm

The following table shows the function on the Alarms tab.

Table 10 - Alarms Tab Description

Function	Action	Security
Alarm Name	Click an alarm name to open the associated P_Alarm faceplate.	None
	Click to acknowledge the alarm.	Acknowledge Alarms (Code F)
	Click to reset and acknowledge all alarms.	

The Reset and Acknowledge All Alarms button is enabled, the panel behind the alarm blinks, and the Alarm Acknowledge button is enabled if the alarm requires acknowledgment. Click the button with the checkmark to acknowledge the alarm.

Refer to the Rockwell Automation Library of Process Objects: Common Alarm Block (P_Alarm) Reference Manual, publication [SYSLIB-RM002](#), for more information.

E300 Overload Relay (EtherNet/IP) Faceplate Help

E300 Overload Faceplate Help

Status Indicators

- Invalid Configuration
- Communication Failure
- Communication Uncertain
- The Device is Not Ready To Operate
- Alarm Inhibit (Suppressed or Disabled)
- Maintenance Bypass Active
- Device in Simulation or Test

Commands

- Operator Command to Trip Overload
- Operator Command to reset the overload trip

Alarms

Pending Trip Warning
The Pending Trip Warning is triggered when a motor overload condition is occurring and an overload trip is imminent.

Overload Trip
The Overload Trip alarm occurs when the overload has tripped.

I/O Fault Alarm
The I/O Fault Alarm is triggered when a controller hardware or communication fault is detected.

Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products.

At <http://www.rockwellautomation.com/support> you can find technical and application notes, sample code, and links to software service packs. You can also visit our Support Center at <https://rockwellautomation.custhelp.com/> for software updates, support chats and forums, technical information, FAQs, and to sign up for product notification updates.

In addition, we offer multiple support programs for installation, configuration, and troubleshooting. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://www.rockwellautomation.com/services/online-phone>.

Installation Assistance

If you experience a problem within the first 24 hours of installation, review the information that is contained in this manual. You can contact Customer Support for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the Worldwide Locator at http://www.rockwellautomation.com/rockwellautomation/support/overview.page , or contact your local Rockwell Automation representative.

New Product Satisfaction Return

Rockwell Automation tests all of its products to help ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete this form, publication [RA-DU002](#), available at <http://www.rockwellautomation.com/literature/>.

Rockwell Automation maintains current product environmental information on its website at <http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleedlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication SYSLIB-RM051A-EN-P - August 2014

Copyright © 2014 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.